Keys

Electronic key

Smart access system with push-button start (→P.8, 17)

Mechanical key

- Locks and unlocks the doors
- Locks and unlocks the glove box
- Locks and unlocks the armrest door

The mechanical key is stored inside the electronic key. To extract the key, release the latch and pull.

Wireless remote control

1 Locks the doors
2 Unlocks the doors
3 Opens the trunk
4 Sounds the alarm
Use the alarm to attract attention to the vehicle in order to help deter break-ins.
(To stop the alarm, push any button on the wireless remote control.)

The wireless remote control can also be used to open the windows and moon roof (standard type).
To do so, simply press and hold button.

Smart Access System with Push-button Start

The smart access system with push-button start allows you to enter and exit the vehicle or start the engine by simply carrying the electronic key in your pocket or bag.
For details on starting the engine, see page 17.

Entering the vehicle

To unlock the vehicle, simply grasp any of the door handles.

Exiting the vehicle

To lock the vehicle, press the lock button on any of the door handles.

To close the windows and the moon roof (standard type), press and hold the lock button.

Opening the trunk

To open the trunk, press the trunk release button.

For details on what to do when the electronic key battery becomes discharged, see page 48.

Theft Deterrent System

The theft deterrent system includes the following features to help protect your vehicle from theft.

Engine immobilizer system

The engine immobilizer system prevents the engine from being started in the event that an attempt is made to start the vehicle using an unregistered key.
The security indicator light flashes to indicate that the system is set.

Alarm

The system sounds the alarm and flashes lights when forcible entry is detected.
To set the alarm: lock all the doors from outside the vehicle. The security indicator light comes on to indicate that the alarm is in its preparation state. When the indicator light begins to flash, the system is armed.
To deactivate or stop the alarm: start the engine, or unlock the doors or trunk using the electronic key or the wireless remote control.

Steering lock

The steering wheel locks when the engine switch is in OFF mode.

To release the steering wheel lock, gently turn the wheel left or right while pressing the engine switch.